

SERVICE SOLUTIONS // HOW TO

HOW TO PROLONG THE LIFETIME OF YOUR FAT-O-MEAT'ER II™ WITH PROPER HANDLING AND CLEANING

Handling of the Fat-O-Meat'er II™

Correct handling will avoid that fat and water enters the housing

1. Use your right hand to handle the Fat-O-Meat'er II™
2. Use our left hand to find the right measuring position
3. When the right hand is needed for operating other equipment, ensure to hold the Fat-O-Meat'er II™ with the left hand as shown in **picture A**


Daily maintenance and cleaning

1. Disconnect the probe from the cable and mount the dust cap
2. Clean the outside of the probe using a damp cloth
3. De-grease with a cloth dampened in technical alcohol
4. Check whether sharpening of the probe tip is needed

IMPORTANT: Replace the probe if the height of the knife is less than 8 mm - see **picture B** for correct measurements

Weekly maintenance

A technician with the proper training should open the housing and check for fat and/or water inside the housing and the bushings that guide the rods



CONTACT

Central/Eastern Europe
+49 252 185 070
service.de@frontmatec.com

Northern Europe, Kolding
+45 36 999 099
service.kol.dk@frontmatec.com

Northern Europe, Tandslet
+45 74 407 644
service.tan.dk@frontmatec.com

Southern Europe
+34 932 643 800
service.es@frontmatec.com

Western Europe
+31 886 294 000
service.nl@frontmatec.com